






PUMP SERVICE BOOK




TC-X250A TC-X250S TC-X250F
TC-X200A TC-X200S
Series Pumps



2





2-①

AC AN AE AV AT AH AS
FC FN FE FV FT FH FS




2-②

SC SN SE SV ST SH SS




3-①

AC SC FC
AN SN FN
AE SE FE
AV SV FV











3-②

AH SH FH
AS SS FS














3-③

AT ST FT



4









6

6-1

AH,(AS),FH,(FS)

AT,FT





6

6-3

AH,(AS),SH,(SS) AT,FT

